




DATAKOM

DKG-3XX/5XX RELAY EXTENSION UNIT



MOUNTING INSTRUCTIONS

TERMINAL-26 : Connect BAT+

TERMINAL-27 : Connect BAT-

TERMINALS-29-30 : Connect these terminals together for 12V-DC operation (for 24V-DC operation leave open)

DATA INPUT : Connect one end of the telephone cable (type 6P6) to this connector. Connect the other end of the cable to the DKG-3XX/5XX unit

PROGRAMMING INSTRUCTIONS

Each relay's function is programmable from the base DKG-3XX/5XX unit. RL1 corresponds to RELAY-8 on base unit. Please refer to the DKG-3XX/5XX user's manual for more details.



DATAKOM